miamily
A SWISS BRAND

HIPSTER™ PLUS

Bruksanvisning

SE

VARNING

VIKTIGT! SPARA FÖR FRAMTIDA BRUK

- Läs först igenom bruksanvisningen innan du monterar och börjar använda bärselen
- Spara bruksanvisningen för framtida bruk
- Kontrollera att alla spännen, remmar och justeringar sitter säkert inför varje användning
- Kontrollera att det inte finns några trasiga sömmar, trasiga remmar eller skadade fästen inför varje användning
- Se till att barnet placeras rätt i HIPSTER™ PLUS-bärsele för barnets säkerhet och för rätt benplacering
- Barnet måste vara vänd mot dig tills det att han eller hon kan hålla huvudet upprätt
- För tidigt födda barn, spädbarn med andningsbesvär samt spädbarn under 4 månader kan riskera att kvävas. Av säkerhetsskäl, kontakta en läkare om bärselen är lämplig att användas för just ditt barn
- Använd aldrig bärselen om din balans eller rörlighet är nedsatt på grund av träning, trötthet eller annat medicinskt tillstånd
- Använd aldrig bärselen vid matlagning eller städning som medför hög värme eller exponering för kemikalier
- Använd aldrig bärselen när du kör bil eller är medpassagerare
- Den här bärselen är inte lämplig att användas vid sportaktiviteter

VARNING
RISK FÖR FALLSKADOR OCH KVÄVNING

RISK FÖR FALLSKADOR —
Barnet kan falla ur en bred benöppning eller ur bärselen

- Se till att alla spännen och remmar sitter fast ordentligt före användning
- Var särskilt försiktig när du lutar dig framåt
- Böj dig med knäna, ej med ryggen
- Bärselen är endast avsedd för barn mellan 4-20 kg
- Håll ditt barn nära dig hela tiden när du använder bärselen utan bärremmar

KVÄVNINGSRISK —
Spädbarn under 4 månader kan kvävas i bärselen om ansiktet pressas för hårt mot din kropp.

- Spänn inte fast barnet för hårt mot din kropp
- Ge alltid utrymme för huvudrörelser
- Håll alltid spädbarnets ansikte fritt från hinder

HIPSTER™ PLUS

HIPSTER™ PLUS är det nya sättet att bära ditt barn på sex olika sätt. Inga mer värkande armar och ont i ryggen. HIPSTER™ PLUS är en unik, ergonomisk bärsele med integrerad 3D-sits som hjälper dig att bära ditt barn betydligt längre, bekvämare och smidigare. Den mångsidiga HIPSTER™ PLUS-bärselen ger ditt barn mer utrymme att utforska världen. Det breda bältet ger ett optimalt ergonomiskt ryggstöd och fördelar ditt barns vikt jämnt över nedre delen av ryggen och axlarna. Detta för att minska negativa effekter av eventuell dålig hållning och trötthet. Designad för bästa säkerhet och enkelhet . Ett snabbt grepp, så lyfter du i och ur barnet på någon sekund.

1.

2.

3.

Innehåll

1. Sits
2. Bärremmar
3. Avtagbar framficka
4. Huvudskydd

4.

SE

5 ENKLA STEG FÖR HIPSTER PLUS SITS

1. Spänn HIPSTER™ PLUS-bältet runt midjan, med sitsen placerad ovanför höfterna.
2. Fäst HIPSTER™ PLUS-kardborreband så att det sitter tätt. Ju stramare bältet sitter åt, desto mera stöd får ryggen.
3. Se till att du för spännet genom den elastiska säkerhetsöglan på remmen innan du knäpper igen spännet som en extra säkerhetsåtgärd.
4. Fäst bältet med det justerbara spännet. Lyssna efter klickljudet för att vara säker på att spännet sitter fast ordentligt. Drag och justera säkerhetsremmen tills det sitter stadigt runt höfterna.
5. Placera barnet på HIPSTER™ PLUS-sitsen, vänd inåt eller utåt.

För steg-för-steg-videoinstruktioner, besök: www.miamily.com/instructions

1. Sits
2. Säkerhetsspänne för dragkedja
3. Sidoficka
4. Justerbart säkerhetsspänne
5. Elastisk säkerhetsögla
6. Stor förvaringsficka under sitsen

HIPSTER™ PLUS

BÄRSELE

SE

1. Blixtlåsfäste
2. Säkerhetsspänne för dragkedja
3. Justerbart ryggband
4. Axelremmar med dubbla justeringar
5. Avtagbar framficka

SE

INÅTVÄNT BÄRANDE + UTÅTVÄNT BÄRANDE

1. När du har tagit på dig HIPSTER™ PLUS-sitsen (*se sid 6), sätt ihop sitsen och bärselen med hjälp av dragkedjan.
2. Se till att klicka i de två säkerhetsspännena i början och i slutet av blixtlåset (som kopplar ihop bärselen med sitsen) som en andra säkerhetsåtgärd.
3. Med bärselen hängande ner framför dig, placera din bebis på 3D-sitsen vänd mot bröstet (för det inåtvända läget) eller vänd utåt (för det utåtvända läget). Se till att barnets ben är placerade på vardera sida av sitsen.
4. Använd din vänstra hand för att tryggt stödja din bebis. Använd din högra hand för att nå höger axelrem, dra armen genom öglan och placera axelremmen över din högra axel.
5. Använd din högra hand för att tryggt stödja din bebis. Använd din vänstra hand för att nå fram till vänster axelrem, dra armen genom öglan och placera axelremmen över din vänstra axel.
6. Spänn fast det justerbara nackbandet med båda händerna bakom nacken. Den justerbara ryggremmen ska sitta under nacken längs skulderbladet. Om ryggremmen är för låg och du inte når, justera den högre på axelremmen. Om det är för svårt att justera med ditt barn i höftstolen, justera höjden på ryggremmen innan du placerar barnet där i.
7. Justera axelremmarnas längd med de justerbara remmarna under dina armar. Spänn fast bebisen mot din kropp och se till att alltid ha utrymme för huvudrörelse. Håll alltid ditt barns ansikte fritt från hinder.
8. Kontrollera alltid (en sista gång) att alla remmar och spännen sitter fast ordentligt!
9. För steg-för-steg- videoinstruktioner: www.miamily.com/instructions

AMNING

1. Följ instruktionerna för inåtvänt bärande: Likadant som inåtvänt bärande fast med sitsen lägre på höften, så att ditt barns ansikte är i höjd med bröstnivå. Lossa axelremmarna om så behövs för att ge ditt barn mer utrymme.
2. Amma barnet i bärselen och använd huvudskyddet för lugn och ro.

ANVÄND HUVUDSKYDDET

1. När ditt barn sover eller behöva vila ostört, fäst huvudskyddet på bärselen med hjälp av knapparna.
2. Tag huvudskyddets vänstra sida och sträck ut det för att täcka ditt barns huvud. Knäpp knapparna på vänster axelrem. Du kan justera huvudskyddets höjd med hjälp av de olika knapparna.
3. Gör likadant på den högra sidan av huvudskyddet.

SE

BÄRA PÅ RYGGEN

1. När du har tagit på dig HIPSTER™ PLUS -sitsen (*se sid 6), drag igen dragkedjan mellan 3D-sitsen och bärremmarna.
2. Kom ihåg att klicka i de två säkerhetsspännena i början och i slutet av dragkedjan (som kopplar ihop bärremmarna med sitsen) som en extra säkerhetsåtgärd.
3. Med bärselen hängande ned framför dig, för sitsen till höger höft.
4. Placera barnet på sitsens bas, vänd mot bröstet.
5. Använd din vänstra hand för att hålla i barnet och dra upp bärselen med din högra hand mot ditt barns rygg.
6. Använd vänster hand för att nå vänster axelrem bakom dig. Dra igenom armen och placera den vänstra axelremmen över din vänstra axel. Var noga med att hela tiden hålla i barnet med din högra hand.
7. Luta dig lite framåt så att ditt barn lutar sig mot dig och flytta sitsen till din rygg.
8. Stoppa in din högra hand i höger axelrem och för din högra arm genom axelremmen.
9. Klicka i spännet på nackbandet med båda händerna. Nackbandet ska sitta framför bröstet. Om det sitter för högt eller för lågt, kan du justera nackbandet på axelremmens bakre rem.
10. Justera axelremmarnas längd med de justerbara remmarna under dina armar. Spänn fast barnet mot kroppen och ge alltid utrymme för huvudrörelser. Håll ditt barns ansikte fritt från hinder hela tiden.
11. Kontrollera att alla remmar och spännen sitter fast innan användning.
12. För steg-för-steg-videoinstruktioner, besök: www.miamily.com/instructions

OBS! / Det här är en mer avancerad position och passar barn från 7 månader som själva kan hålla sig upp medan föräldern justerar bärselen. Barnet måste ha full kontroll över sitt huvud och måste kunna se över föräldrarnas axlar. Se våra videoinstruktioner på www.miamily.com/instructions och be någon att hjälpa dig när du försöker få till denna position för första gången.

Bära på ryggen

Inåtvänt

Utåtvänt

SE

GARANTI

MiaMily har 2-års garanti på produkten från köptillfället. Vid frågor om garanti eller reklamation, vänligen kontakta oss: Amvina AB, Kemistvägen 10, 18379 Täby Tel: 08-7328850 E-post: kundtjanst@amvina.se

UTFÖRD SÄKERHETSTEST

HIPSTER™ PLUS-bärsele har godkänts av följande:

För USA / KANADA: HIPSTER™ PLUS-bärsele uppfyller den amerikanska säkerhetsstandarden ASTM F2236 och CPSIA 2014 och Consumer Product Safety Improvement Act från 2014.

För EUROPA: HIPSTER™ PLUS-bärsele uppfyller standarden EN71-3.

GLOBALT: HIPSTER™ PLUS-bärsele uppfyller säkerhetsstandarden EN13209-2: 2005 och 6P.

Skötsel av HIPSTER™ PLUS-bärsele

HIPSTER™ PLUS-bärsele är tillverkad av 100% polyester / 100% organisk bomull, fläckbeständigt material och kan tvättas i maskin. Tag bort sitsens plastinsats innan du tvättar bärselen. Tvätta ENDAST med kallt vatten. Lufttorka, HIPSTER™ PLUS-bärsele skall inte torktumlas! För lättare rengöring, torka av med en fuktig handduk.

KONTAKTA OSS

Amvina AB, Kemistvägen 10, 18379 Täby

Tel: 08-7328850

E-post: kundtjanst@amvina.se

EN

WARNING

IMPORTANT! KEEP FOR FUTURE REFERENCE

- Read all instructions before assembling and using the HIPSTER™ PLUS carrier
- Keep instructions for future use
- Check to assure all buckles, snaps, straps and adjustments are secure before each use
- Check for ripped seams, torn straps or fabric, or damaged fasteners before each use
- Ensure proper placement of child in HIPSTER™ PLUS for safety and leg placement
- Child must face towards you until he or she can hold head upright
- Premature infants, infants with respiratory problems, and infants under 4 months old are at risk of suffocation - for safety reasons, be sure to check with your doctor if HIPSTER™ PLUS is suitable for use with your baby
- Never use the HIPSTER™ PLUS carrier when balance or mobility is impaired due to exercise, drowsiness, or medical conditions
- Never use the carrier while engaging in activities such as cooking and cleaning which involve a heat source or exposure to chemicals
- Never wear the carrier while driving or being a passenger in a motor vehicle
- This carrier is not suitable for use during sporting activities
- Your balance may be adversely affected by your movement and that of your child

WARNING
FALL & SUFFOCATION HAZARD

FALL HAZARD —
Infants can fall through a wide leg opening or out of carrier.

- Before each use, make sure all buckles, snaps, and straps are secure
- Take special care when leaning forward
- Never bend at waist, bend at knees
- Only use this carrier for children between 4-20kg
- Hold your baby close at all times when using HIPSTER™ PLUS without carrier straps

SUFFOCATION HAZARD —
Infants under 4 months old can suffocate if face is pressed too tight against your body.

- Do not strap the baby too tight against your body
- Always allow room for head movement
- Keep infant's face free from obstructions at all times

HIPSTER™ PLUS

EN

HIPSTER™ PLUS the new way to carry your baby, No more achy arms and sore backs. HIPSTER™ PLUS is a unique, ergonomic baby carrier with an integrated hip seat to help you carry your little one significantly longer, more comfortably and effortlessly. When used with the interchangeable carrier systems, HIPSTER™ PLUS allows your baby more breathing room to explore the world without feeling enclosed in . Its wider belt provides optimal ergonomic back support, distributing your baby's weight evenly throughout the lower back and shoulders to help minimize any long term effects from bad posture and fatigue. Designed with a safe but quick release system, one simple movement is all that is needed to get your little one in and out in seconds, or even with just one hand.

1.

2.

3.

CONTENTS

1. hip seat base
2. double shoulder top carrier (with front pocket layer removed)
3. removable front pocket layer (easily attached with zipper)
4. head cover

4.

5 SIMPLE STEP

EN

FOR THE HIPSTER™ PLUS HIP SEAT

1. Wrap the HIPSTER™ PLUS belt around your waist, with the seat positioned on your side, above your hips.
2. Secure the HIPSTER™ PLUS velcro belt so that it is snug; the tighter the belt, the more support it will provide your back.
3. Make sure you slide the buckle through the elastic safety loop on the belt before closing the buckle together as an extra security measure.
4. Fasten your belt with the adjustable security buckle strap. Listen for the "click" sound to make sure the buckle is securely engaged. Pull and adjust the security buckle strap until it is snug around your hips.
5. Place baby on the HIPSTER™ PLUS hip seat facing in or facing out or on your side

For step-by-step video instructions, please visit: www.miamily.com/instructions

1. Hip seat
2. Security buckle for zipper
3. Side pocket
4. Adjustable security buckle
5. Elastic safety loop
6. Large storage pocket under 3D hip seat

HIPSTER™ PLUS

DOUBLE SHOULDER TOP CARRIER

EN

1. zipper attachment
2. security button for zipper
3. adjustable back strap
4. straps for shoulder strap adjustment
5. removable front pocket layer

EN

FACE-IN CARRY + FACE-OUT CARRY

1. Once you have put on the HIPSTER™ PLUS hip seat base (see 5 Simple Steps for the HIPSTER™ PLUS Hip Seat), zip the top of the Hip Seat to the bottom of the Double Shoulder Top Carrier.
2. Make sure to button the 2 security buttons at the beginning and at the end of the zipper (which connects the Double Shoulder Top Carrier and Hip Seat) as a second security measure.
3. With the Double Shoulder Top Carrier hanging down in front of you, place your baby on the hip seat base facing towards your chest (for the Face-In Carry position) or facing outwards (for the Face-Out Carry position). Make sure your baby's legs are properly positioned on each side of the hip seat.
4. Using your left hand to support your baby for safety, use your right hand to reach for the right shoulder strap, put your arm through the loop and place the shoulder strap over your right shoulder.
5. Using your right hand to support your baby for safety, use your left hand to reach for the left shoulder strap, put your arm through the loop and place the shoulder strap over your left shoulder.
6. Reach over your shoulder with both hands over your head behind your neck, and buckle in the adjustable back strap. The adjustable back strap should sit right below your neck along the shoulder blades. If the back strap is too low and you cannot reach, adjust it higher on the shoulder strap. If it is too difficult to adjust with your baby on the hip seat, adjust the height of the back strap before you place your baby in.
7. Adjust the length of the shoulder straps with the adjustable shoulder straps under your arms. Do not strap the baby too tight against your body and always allow room for head movement. Keep your baby's face free from any obstructions at all times.
8. Make a final check to assure all straps and buckles are secured.
9. For step-by-step video instructions, please visit: www.miamily.com/instructions

BREASTFEEDING

1. Follow the instructions of Double Shoulder Top Carrier: Face-In Carry but wear the hip seat lower on your hip so that your baby's face is at breast level. Loosen the shoulder straps if necessary to give your baby more room.
2. Nurse baby in the carrier and cover with the head cover for more privacy.

USING THE HEAD COVER

1. When your baby is asleep or when you want to keep out distractions, attach the head cover to the carrier, buttoning the two bottom buttons first.
2. Take the left side of the head cover and extend it to cover your baby's head. Button the buttons on the left shoulder strap. You can adjust the height of the head cover by using the different buttons.
3. Repeat with the right side of the head cover.

EN

BACK CARRY

1. Once you have put on the HIPSTER™ PLUS hip seat base (see 5 Simple Steps for the HIPSTER™ PLUS Hip Seat), zip the top of the Hip Seat to the bottom of the Double Shoulder Top Carrier.
2. Make sure to button the 2 security buttons at the beginning and at the end of the zipper (which connects the Double Shoulder Top Carrier and Hip Seat) as a second security measure.
3. With the Double Shoulder Top Carrier hanging down in front of you, slide the hip seat to your right hip.
4. Place your baby on the hip seat base, facing towards your chest.
5. Using your left hand to support your baby, pull up the Double Shoulder Top Carrier with your right hand against your baby's back.
6. Use your left hand to reach behind you for the left shoulder strap, loop your arm through, and place the left shoulder strap over your left shoulder. Be sure to keep supporting your baby with your right hand.
7. Lean slightly forward to have your baby leaning against you, and slide the hip seat base to your back.
8. Slide your right hand into the right shoulder strap, and loop your right arm through the shoulder strap.
9. Reach both hands in front of your chest to secure the adjustable back strap. The back strap should sit in front of your chest. If it's too low or too high, you can adjust the back strap on the shoulder strap
10. Adjust the length of the shoulder straps with the adjustable shoulder straps under your arms. Do not strap the baby too tight against your body and always allow room for head movement. Keep your baby's face free from any obstructions at all times.
11. Make a final check to assure all straps and buckles are secured.
12. For step-by-step video instructions, please visit: www.miamily.com/instructions

TIP / This is a more advance carry position and is suitable for babies 7 months old who can hold on to the parent while adjusting the carrier. Baby must have full control of his head and can look over parent's shoulder. Please watch our video instructions at www.miamily.com/instructions and have someone help you when you try this position for the first time.

BACK CARRY

FACE IN

FACE OUT

EN

WARRANTY

MiaMily warrants that our products are free from any manufacturing defects in material or workmanship for a period of one (2) years from the original date of purchase. If you are in need of warranty or repair for a MiaMily product, please contact us at questions@miamily.com

SAFETY TESTING

HIPSTER™ PLUS has been submitted and approved by global wide safety standards.

For the US/ *CANADA:* HIPSTER™ PLUS meets the US safety standard ASTM F2236 and CPSIA 2014, and the Consumer Product Safety Improvement Act of 2014.

For EUROPE: HIPSTER™ PLUS meets the EN71-3 standard.

GLOBALLY: HIPSTER™ PLUS meets the EN13209-2:2005 and 6P safety standard.

HIPSTER™ PLUS CARE

HIPSTER™ PLUS is made with 100% polyester / 100% organic cotton, stain resistant material, and is machine washable. Remove hip seat's plastic insert before washing. Use with cold water in gentle cycle ONLY. Air dry, DO NOT PUT HIPSTER™ PLUS IN DRYER. For light cleaning, simply wipe with a wet towel.

CONTACT US

Overtea SA

Via Cara' 20b, manno, 6928, Switzerland

questions@miamily.com

miamily
A SWISS BRAND

www.miamily.com

No. 1921
May 6, 2021